
How is a 35kV busbar grounded



Overview

Learn how to ground a busbar system with NEC requirements. Step-by-step guide covering grounding conductors, bonding, and common mistakes to avoid.

Key Takeaways

Grounding a 35kV busbar requires connecting the busbar to a low-impedance grounding system, often through an arc suppression coil or neutral grounding resistor, to safely manage fault currents and protect personnel and equipment.

Key Principles

Purpose of Grounding Grounding a 35kV busbar ensures that any fault current, such as a single-phase-to-ground fault, is safely directed to earth, minimizing the risk of electric shock, equipment damage, or fire. It also stabilizes the system voltage during transient events and allows protective relays to operate correctly. Neutral Connection High-voltage busbars are typically grounded through the system neutral.

For 35kV systems, this may involve a resistor or arc suppression coil (Petersen coil) connected between the neutral point and ground. This limits fault current magnitude and reduces transient overvoltages. Grounding Electrode System The busbar should be connected to a substation grounding grid or mat, which consists of interconnected copper conductors or rods buried in the earth.

© 2026 EXF OPTICAL NETWORKS - All rights reserved

Each piece of equipment, including transformers, switchgear, and bus supports, should have its own connection to the grounding grid to equalize potential and prevent dangerous voltage differences. Equipment Bonding All exposed metal parts of the busbar, supports, and associated structures must be bonded to the grounding system. This ensures that anyone touching the equipment cannot experience a hazardous shock if a high-voltage fault occurs.

Fault Detection and Protection Grounding should be coordinated with protective devices. In 35kV systems, voltage transformers (VTs) and relay protection monitor for ground faults. The grounding system must allow fault currents to flow through the arc suppression coil or neutral resistor so that alarms and protective actions can be triggered without tripping the entire system unnecessarily.

Installation Steps

Site Assessment: Evaluate the substation layout, busbar location, and proximity to the grounding grid. Ensure accessibility for maintenance. Busbar Mounting: Secure the busbar on insulated supports, ensuring mechanical stability and clearance from other phases.

Ground Conductor Connection: Connect a heavy copper conductor from the busbar neutral or designated grounding point to the substation grounding grid. Use multiple connections if necessary to reduce impedance. Arc Suppression Coil or Resistor: Install the neutral grounding device according to system design.

Ensure it is rated for the expected fault current and voltage. Continuity Testing: Verify electrical continuity between the busbar, neutral grounding device, and grounding grid. Inspect all connections visually and mechanically.

Documentation and Safety Checks: Record all connections, verify compliance with IEEE Standard 80 and local regulations, and ensure personnel are trained on safe operation.

Safety Considerations

Always de-energize the busbar before making grounding connections. Use insulated tools, gloves, and protective equipment rated for high voltage. Ensure grounding conductors are sized to carry the maximum expected fault current without damage.

Avoid creating loops or high-impedance paths that could prevent proper fault current flow. Proper grounding of a 35kV busbar is critical for system reliability, personnel safety, and regulatory compliance, and should always follow substation design standards and manufacturer recommendations.

© 2026 EXF OPTICAL NETWORKS - All rights reserved

Article Content

How to Ground a Busbar System: NEC Grounding Requirements

Learn how to ground a busbar system with NEC requirements. Step-by-step guide covering grounding conductors, bonding, and common mistakes to avoid.

35 kV busbar_Baiduwiki

The 35 kV busbar is a critical node in the power system at the 35 kV voltage level, used for collecting and distributing electrical energy, connecting the generation side with the transmission network. Its

35kV busbar of substation

Here, we provide an overview of common substation busbar configurations—Single Bus, Main and Transfer, Double Breaker/Double Bus, Ring Bus/Ring Main, and Breaker and a Half.

35kV Distribution Line Single-Phase Ground Fault Handling

Since the neutral voltage is non-zero, current flows through the arc suppression coil, and “busbar grounding” signals may appear depending on the magnitude of the displacement voltage.

What Is Busbar Grounding and Why Is It Important for Electrical

Busbar grounding connects conductive busbars to the earth, ensuring safe dissipation of fault currents. The system uses copper or aluminum grounding busbars, providing low-resistance

Understanding Electrical Ground Bus Bar: An Ultimate Guide

The electrical ground bus bar plays a pivotal role in this process by providing a dedicated and organized way to attach all grounding wires, ensuring a uniform and efficient grounding system.

How are the grounding resistor value and grounding transformer for a

The main purpose of using neutral resistor grounding for the 35 kV substation system is to limit system overvoltage and achieve fast and accurate fault line selection under single-phase

Busbars: Electrical Types, Sizing & Design Guide

In panels and distribution equipment, a neutral busbar and a ground busbar serve different purposes. A neutral busbar

35kV Substation Electrical Design | PDF | Transformer

© 2026 EXF OPTICAL NETWORKS - All rights reserved

Grounding design must ensure low resistance paths, appropriate use of natural and artificial grounding methods, and robust mechanical strength in extreme conditions.

35kV RMU Busbar Failure Due to Installation Errors Analysis

When the fault occurred, the voltage of phases A and C on the 35kV busbar No.1 rose to line voltage while the voltage of phase B approached zero. This is characteristic of a typical single-phase metallic

Electrical busbar system

Content and types of busbar systems A busbar system usually contains couple of busbar holders, busbars, Adapters to mount devices, clamps either with

Electrical Design Handbook

Normal 66 kV system configurations will be busbars fed from transformers with the maintenance coupler disconnector switches open. Harmonic Filtering and Reactive Power Compensation shall be

35kV F Busbar system

12-35kV 1250A Busbar connector Apply to the cabinet connection of 12-35kV 1250A RMU. Adopt the 35kV 2# Inner cone socket. Meet for the 1250A current requirements .

What''s in the Code? Applying the NEC to medium

These systems are called medium-voltage. Those of more than 35 kV are high-voltage. The NEC provides several rules related to grounding of these systems and equipment. Part X of

Insulation of bus bars at 35 kV

The installation of heat shrink to outdoor 35kV busbars should not have any bearing on safety clearances. The conductor would be classed as covered, rather than insulated. It would have

Why is the 10kV busbar not grounded when the 35 busbar is grounded

In panelboard systems, this is often a green screw located in the grounded conductor busbar, which must be tightened down to make good contact with the enclosure. Understanding why neutral and

35kV busbar of substation

A busbar is a grounded metal enclosure, containing factory-mounted, bare or insulated conductors, which are usually copper or aluminum bars, rods, or How to Design Busbar Systems for Substations

© 2026 EXF OPTICAL NETWORKS - All rights reserved

Neutral Bar vs. Grounding Bar: What''s the Critical

N N bar neutral busbar neutral terminal bar neutral link A neutral bar is not a spare grounding point. It is part of the normal current-carrying circuit.

Contact Us

Continue your research online:

Website: https://explosivefunctions.co.za
Technical inquiry: https://explosivefunctions.co.za/contact.html
EU project coordination: Parque das Nações, Lisbon, Portugal

This document is for preliminary research. Verify specifications against current standards, product documentation and project requirements.

© 2026 EXF OPTICAL NETWORKS - All rights reserved