What to do if the optocoupler is not working properly



Overview

Understanding how to accurately test and verify the proper functionality of an optocoupler is essential for technicians and hobbyists alike.

Key Takeaways

When an optocoupler fails, it can stop transmitting signals, degrade performance, or compromise electrical isolation, depending on whether the LED or phototransistor fails.

Common Failure Modes

Optocouplers consist of an LED and a phototransistor. Failures can occur in either component: LED Failure: The LED may burn out or degrade due to overcurrent, high temperatures, or electrical surges. When this happens, the LED stops producing light, leaving the phototransistor off and preventing signal transmission.

Phototransistor Failure: The phototransistor can fail due to excessive voltage, static discharge, or mechanical stress. It may fail shorted, causing the output to be pulled to the negative rail, or open, resulting in no output. Current Transfer Ratio (CTR) Degradation: Over time, the efficiency of light-to-current conversion can decrease, reducing the output signal strength and potentially causing erratic circuit behavior.

© 2026 EXF OPTICAL NETWORKS - All rights reserved

Environmental Damage: Corrosion, contamination, or mechanical stress can impair the optocoupler's performance. Effects on CircuitsThe impact of a failed optocoupler depends on its role in the circuit: Signal Interruption: If the LED or phototransistor fails open, the output signal may cease entirely, causing downstream circuits to stop functioning. Voltage Fluctuations: In feedback loops, such as in switched-mode power supplies, a failed optocoupler can lead to uncontrolled output voltages, including spikes or dips, because the feedback signal is lost.

Shorted Output: If the phototransistor fails short, it can pull the output to ground or the negative rail, potentially disabling the controller or damaging other components. Isolation Compromise: Exceeding the optocoupler's voltage rating can create a conductive path across the isolation barrier, allowing high voltage to reach sensitive circuits, which may be hazardous.

Signs of Failure

Erratic or unstable output signalsComplete loss of signal transmissionUnexpected voltage levels or oscillationsMalfunctioning of devices relying on isolated signals, such as microcontrollers or power supply feedback loops Mitigation and Design ConsiderationsEnsure proper drive current and voltage ratings to prevent premature LED or phototransistor failure Use protective elements like fuses, suppressor diodes, or series resistors to limit surges Consider double isolation or redundant optocouplers in critical applications to maintain safety if one fails Monitor CTR degradation in long-term designs to anticipate performance decline In summary, optocoupler failure can range from subtle signal degradation to complete circuit malfunction, and the consequences depend on which component fails and the circuit's design.

Proper design, protection, and monitoring can mitigate these risks.

Article Content

How to Check Optocoupler with Multimeter? – A Simple Guide

Understanding how to accurately test and verify the proper functionality of an optocoupler is essential for technicians and hobbyists alike.

How to Test Optocoupler with Digital Multimeter? Quick & Easy Guide

Understanding how to use a DMM to test an optocoupler empowers you to identify common failure modes and ensure the reliable operation of your circuits. This blog post provides a

interface chip-How to Diagnose and Repair 6N137SDM

Once you understand the common issues with the 6N137SDM and have your tools ready, it''s time to move on to the diagnosis and repair process. The following is a step-by-step guide to help

© 2026 EXF OPTICAL NETWORKS - All rights reserved

Optocouplers

Optocouplers If any optically isolated input on the controller is not working, follow the steps below to identify the cause.

Optocoupler not working properly, current in diode

If that works, then replace the gate with a fresh one from a reliable source (following ESD precautions). If it does not work, then inspect the PCB under a microscope or magnifier, preferably

Find a Bad Photocoupler with a Multimeter | ODG

Test a photocoupler by setting a multimeter to resistance mode. A good one shows high resistance (OL) with the input LED off and low resistance with it on.

Common Problems with PC817 Optocouplers and How to Solve Them

Below is a detai LED analysis of common problems with the PC817 optocoupler and practical steps to solve them. 1. Problem: No Output Signal. Possible Causes: Faulty LED inside the

Optocoupler Tester Circuit: Build, Test & Troubleshoot

Build a simple DIY optocoupler tester circuit with two LEDs and a 3.7V battery. Test 4-pin and 6-pin optocouplers instantly, no instruments needed. Full diagram included.

Testing Methods for Optocouplers | PDF

The document describes 3 methods for testing opto-couplers to determine if they are functioning properly or bad. The methods involve using a multimeter to measure resistance or voltage across the

How to Test an Optocoupler in Seconds! | Easy Electronics Hack ⚡

Test your optocoupler in seconds! ⚡ Learn a simple way to check if it''s working or dead using a multimeter.

Optocoupler not working properly, current in diode

The optocoupler might not be saturating because it does not have enough "gain", called the Current-Transfer-Ratio (CTR). Your part is rated for a CTR of 100-200%.

ESP32 Smart Relay for Home Assistant (ESPHome) –

Build a Shelly-style ESP32 smart relay for Home Assistant using ESPHome. Safe wiring, relay module tips, GPIO choices, YAML, and reliability

Optocoupler

© 2026 EXF OPTICAL NETWORKS - All rights reserved

Hello and Happy New Year. Nearly every video, tutorial and article concerning Optocouplers goes into detail as to what they do and how they work. Rarely is any information given

interface chip-How to Diagnose and Repair 6N137SDM

Apply an input signal and measure the output waveform. If the signal is not properly replicated or has significant distortion, the phototransistor might be faulty. Step 4: Check the Drive

Optocouplers

Step 1: Check Ground Side Continuity Using a multimeter, check continuity between the black connector and the marked pin of the optocoupler input that is not working. If there is no continuity, the possible

Optocoupler Issue

I have used an optocoupler/isolator before in a similar circuit, can''t figure out why it isn''t working in this instance, any help would be much appreciated. I am using the Siemens SFH615A, link to...

How to Test Optocoupler with Digital Multimeter? Quick & Easy Guide

A DMM, though not as specialized as dedicated testers, offers a practical and accessible way to assess optocoupler functionality. Throughout this guide, we''ve covered the essential aspects

How to Test Optocoupler with Multimeter? – Easy Step-by-Step Guide

Further investigation, including replacing the optocoupler, reveals that the faulty optocoupler was preventing the motor drive signals from being properly transmitted, causing the

Related Video Reference

This video was associated with the source search result. Verify technical details against current product documentation and project requirements.

© 2026 EXF OPTICAL NETWORKS - All rights reserved

Contact Us

Continue your research online:

Website: https://explosivefunctions.co.za
Technical inquiry: https://explosivefunctions.co.za/contact.html
EU project coordination: Parque das Nações, Lisbon, Portugal

This document is for preliminary research. Verify specifications against current standards, product documentation and project requirements.

© 2026 EXF OPTICAL NETWORKS - All rights reserved