
How to replace a laser diode circuit board



Overview

Replacing a laser diode. A detailed guidance. Setting up DC/DC step. Unscrew 4 screws on the laser housing and take out the radiator with the laser diode.

Key Takeaways

Replacing a laser diode circuit board involves careful disassembly, removing the old diode, installing the new board, and correctly configuring voltage and current to ensure safe operation.

Safety First

Always wear laser-rated safety glasses and ensure the device is powered off before starting. Laser diodes can cause serious eye damage, and some may emit invisible infrared light.

Disassembly

Remove the fan and housing: Unscrew the fan and detach it from the laser housing. Access the radiator: Unscrew the laser housing to remove the radiator, which holds the laser diode. The radiator may consist of multiple parts connected by screws.

Remove the old diode: Carefully unsolder the wires connecting the laser diode to the board. Remove the diode from the radiator and clean off old thermal paste.

Installing the New Laser Diode

Apply new thermal paste to the radiator to ensure proper heat dissipation. Install the new diode into the radiator and reassemble the radiator components. Reconnect wires: Solder the negative (black) wire first to the corresponding wire from the control board.

© 2026 EXF OPTICAL NETWORKS - All rights reserved

Leave the positive (red) wire for later voltage adjustment. Reattach the fan and housing: Ensure all screws are tightened and wires are routed safely.

Replacing the Circuit Board

Select a compatible board: For devices like Sculpfun lasers, boards such as MKS DLC or MKS DLC32 are compatible and can be mounted in the original frame. Connect peripherals: Attach limit switches, relays, and fans if needed. Most 3D printer boards are compatible with laser modules.

Upload firmware: Depending on the board, you may need GRBL or Marlin firmware. Ensure the correct board type is selected in your software to avoid upload errors.

Configuring Voltage and Current

Measure with multimeters: Use one multimeter as an ammeter to measure current and another as a voltmeter to measure voltage. Set maximum voltage: Use the formula V=5. 1−(digits/1000) to calculate the safe DC-DC output voltage.

Exceeding this can damage the diode. Adjust current: Use the potentiometer on the driver circuit to set the current according to the diode's specifications. For example, a typical low-power diode may require 12 mA, while higher-power diodes need precise calibration.

Testing

After installation, power on the device in PWM mode and verify that the laser operates correctly. Check for overheating and ensure the beam is stable. Fine-tune voltage and current as needed.

Notes

If using a standalone laser diode, ensure a constant current driver is used. For modules with integrated boards, simply connecting the red and black wires to the correct voltage is sufficient. Document your wiring and settings to simplify future maintenance.

By following these steps, you can safely replace a laser diode circuit board and ensure proper operation of your laser device.

© 2026 EXF OPTICAL NETWORKS - All rights reserved

Article Content

Replacing a laser diode. A detailed guidance. Setting up DC/DC step ...

Unscrew 4 screws on the laser housing and take out the radiator with the laser diode. The radiator consists of two parts connected by screws. We unscrew the screws and disassemble

Laser diode replacement

In principle, you can use a protected diode. The diode only needs to have the same technical data as current consumption and voltage.

Replacing a Faulty Diode — Step-by-Step Micro Soldering

Quick step-by-step walkthrough of replacing a damaged diode on a circuit board. This Short covers identifying the faulty component, preparing the pads, removing the old diode, cleaning...

Harvesting a Laser Diode From an Optical Drive

Let''s take one apart and get it going as a stand alone laser. It can be used for future projects not limited to light shows, laser engraving, games and experiments.

Diode Laser Board Replacement

Hi Guys I''m trying to replace my Diode with a new board. I''m using my spare board that I got from my 3018 cnc pro. I''m trying to disable the z limit switch but I got stuck on the upload and

How to Replace the Laser Head Connection Wire and

Now both the laser''s ribbon connection cable and the small circuit board have been removed, you can install the new connection set back in the same way. Please

Laser Diode Drive Circuit Design Method and Spice Model

ROHM offers laser diodes (LDs) for Light Detection and Ranging (LiDAR). This application note will introduce ROHM''s LD line-up and show how to design the drive circuits of ROHM LDs.

A Capella: A Unique Compilation | PDF | Wellness

This document contains a long list of words beginning with "ab-" or "ac-". It does not appear to be a coherent text, but rather a collection of unrelated terms.

Make a Simple Laser Diode Module

Make a Simple Laser Diode Module: Laser diodes are quite useful in some ways especially in trigger/alarm systems such as triplight mechanisms or even in DIY

© 2026 EXF OPTICAL NETWORKS - All rights reserved

Mixed-signal and digital signal processing ICs | Analog

Analog Devices is global leader in the design and manufacturing of analog, mixed signal, and DSP integrated circuits to help solve the toughest engineering

How to Build a Laser Diode Circuit

They are used in laser printers, laser fax machines, laser pointers, measurement equipment, bar-code and UPC scanners, and in high-performance imagers, as well as various other applications. These

How to Build a Laser (general Guide) : 8 Steps

How to Build a Laser (general Guide): This is needed to make the actual laser beam. Without this lens, you would have just a very wide, useless spot. The

Mainboard Replacement

Mainboard Replacement Instructions and overview of different types of laser motherboards and integration into Sculpfun lasers.

How to replace a laser diode?

How do I replace the diode of a 5mw 405nm laser pen? I''ve always had an interest in lasers but I have never taken one apart. Right now from what I understand the window in my diode is

Ideal Diode

Are you looking for ideal diode? An ideal diode is a hypothetical device with ideal diode with no resistance and has zero voltage drop when current flows through it. The ideal diode is a simple

DIY Laser Diode Driver || Constant Current Source

DIY Laser Diode Driver || Constant Current Source: In this project I will show you how I extracted a laser diode from a DVD Burner which should have the power to ignite a match. In order to power the diode

Building a laser driver circuit?

Preferably use a diode tester that is voltage limited to maybe 5 V and current limitted to a couple of mA. in a driver circuit for a laser I need to regulate not only voltage but current as well. For a laser diode,

Diode laser etching of a PCB: do it yourself with Endurance lasers

A PCB-board is also known as Printed Circuit Board Assembly (PCBA). Creating a PCB board is one of the many useful and innovative ideas you can use your Endurance laser to do. PCB boards are often

© 2026 EXF OPTICAL NETWORKS - All rights reserved

Related Video Reference

This video was associated with the source search result. Verify technical details against current product documentation and project requirements.

Contact Us

Continue your research online:

Website: https://explosivefunctions.co.za
Technical inquiry: https://explosivefunctions.co.za/contact.html
EU project coordination: Parque das Nações, Lisbon, Portugal

This document is for preliminary research. Verify specifications against current standards, product documentation and project requirements.

© 2026 EXF OPTICAL NETWORKS - All rights reserved